



**NOTES:**

- A. CONDUIT STRAPS TO BE SAME SIZE TO ALLOW LOWER CONDUIT TO MOVE WITHIN STRAP.
- B. SEE TABLE 2- APPROVED METER SERVICE DEVICES.
- C. DO NOT INSTALL ANY ATTACHMENTS ON CONDUIT OR SLIP RISER PER NEC & IRC. SEE SKETCH 55 AND SKETCH 55A.

- D. 50" MINIMUM CLEAR SPACE IN FRONT OF METER BASE. SEE RULE 13, SKETCH 55 AND SKETCH 55A (SIDE VIEW).
- E. DRILL TWO (2) 1/4" HOLES IN BACK OF CONDUIT 3" ABOVE GROUND PRIOR TO PULLING CABLE.
- F. DRILL TWO (2) 1/4" HOLES IN BOTTOMSIDE OF ELBOW PRIOR TO PULLING CABLE.
- G. SEE APPROVED SLIP RISER TABLE.

REFERENCE: CRS 6-19-133, CRS 6-19-134, SKETCH 55 & SKETCH 55A